



MORSE MDC16E SECURITY ALARM OPERATION INSTRUCTIONS

Arming the System:

To arm the system, all zones must be closed or in their normal state. Once the system has been activated you have ____ seconds to leave the building. The system is ready to be armed when the display reads:

SECURITY BY FBN ALL ZONES CLOSED

1. Enter your 4-digit pass code.
2. Then press '**ARM**'.
3. The system display will change to '**SYSTEM ARMING, EXIT NOW**'

At the end of the exit time period, the display will change to '**SYSTEM ARMED**', and the **GREEN** MORSE logo will turn **RED** indicating the system is now on.

Trouble Arming the System:

1. Zone(s) may be open – Enter your 4-digit code followed by the '**SCAN**' key. The display will show you one by one the zones and their conditions. To view each zone, press the '**SCAN**' key repeatedly to find the trouble zone. Correct the open/troubled zone and re-enter your 4-digit pass code to proceed with arming the system.
2. '**REQUEST DENIED**' prompt – caused by hitting 2-buttons at the same time, entering an invalid pass code or entering your combination too quickly. To resolve this situation press the '**CLEAR**' key, then re-enter your pass code.

Disarming the System:

Upon entrance of the building, you have ____ seconds to disarm the system before the sirens sound. You will notice that the **RED** MORSE logo light is lit and the keypad will read '**SYSTEM ARM**' and you will hear a buzzing sound (this sound is only a reminder to turn the system off).

1. Enter your 4-digit pass code
2. The **RED** MORSE logo light will turn **GREEN**
3. '**SYSTEM ARMED**' prompt will erase, buzzing will stop
4. System is off.

WE PROTECT THE THINGS YOU TREASURE
FBN SYSTEMS INC. CENTRAL STATION
(330) 239- 1229
Page 1 of 2

Bypassing Zones:

This option is not to be abused and should only be used on temporary basis for any zones that are bypassed are not monitored.

1. Enter your 4-digit pass code
2. Press the '**SCAN**' key until the desired zone is displayed
3. Press the '**BYPASS**' key
4. The display will change from '**IS OPEN**' to '**IS BYPASSED**'

More than one zone can be bypassed, follow the procedures above until all the zones you want bypassed is complete. The zone/zones are now taken out of the system for this arming period.

Sirens:

By entering your 4-digit pass code the sirens can be turned off. If you hear sirens (even for a second) you must call the Central Station and give them your account number and pass code or the proper authorities will be dispatched.

Alarm Occurrence – Prompt:

The first person entering the building will receive this prompt only if an alarm has occurred. Note the number of alarms that occurred:

1. Then press the '**MEMORY**' key to enter the history aspect of the control.
2. Press the '**SCAN**' key to ratchet through all the zones that caused the alarm. (make note of these zones so they can be checked for damage).
3. Once the building has been checked, press the '**RESET**' key to clear the system.

Smoke Detectors/Fire Alarm:

Turn off the sirens by entering your 4-digit code. Go to each smoke detector and look for a steady **RED** light (this is the detector that caused the alarm-make note so it can be checked if any problems may occur). When the smoke has cleared reset your system by entering your 4-digit pass code.